

Table 12-5 Assembly-Level Replaceable Parts (Continued)

Reference Designator	Description	CD	Part Number
A3A4	Second Converter 8592L, 8593E, 8594E, 8594L, 8594Q, 8595E, and 8596E		5086-7958
A3A5	Input Attenuator 8592L and 8593E 8592L and 8593E, (Options 026 and 027) 8594E, 8594L, 8594Q, and 8595E 8596E	4 3 1 2	33321-60039 33321-60038 33321-60036 33321-60037
A3A6	Dual Mixer 8592L, 8593E, 8595E, and 8596E Low Band Mixer 8594E, 8594L, and 8594Q	2	5086-7952 5086-7748
A3A7	Yig-Tuned Oscillator (YTO) 8592L, 8593E, 8594E, 8594L, 8594Q, 8595E, and 8596E	3	5086-7903
A3A8	Yig-Tuned Filter (YTF) 8592L and 8593E 8592L and 8593E, (Options 026 and 027) Switched Yig-Tuned Filter (SYTF) 8595E 8596E	8 9 2 5	0955-0277 5086-7850 5086-7803 5086-7880
A3A9	Bandpass Filter Assembly 8592L, 8593E, 8594E, 8594L, 8594Q, 8595E, and 8596E	0	9135-0252
A3A10	Directional Coupler 8593E, 8594E, 8594L, 8595E, and 8596E	1	0955-0098
A3A11	Step Recovery Diode 8592L, 8593E, and 8596E	3	0955-0149
A3A12	3 dB Attenuator 8592L, 8593E, and 8596E	3	0955-0412